Polished Concrete Maintenance System

Cleans and restores gloss on existing polished concrete floor surfaces



YES - This surface has been previously polished and is compatible with the WerkMaster Maintenance System



NO - This surface has not been polished and is **not** compatible with the WerkMaster Maintenance Systems

WERKANSTER WITCH COMP CONTROL OF THE CONTROL OF T

WerkMaster ULTRAclean HiLite

006-0136-04 - 1 QT 006-0149-00 - 1 GAL 006-0136-01 - 2.5 GAL 006-0136-00 - 5 GAL

SDS INFO



WerkMaster Pink Buffing/Cleaning Pad

011-0015-00 - 3" Nylon 011-0042-00 - 5" Nylon 011-0077-00 - 7" Nylon 011-0046-00 - 8" Nylon

011-0024-00 - 21" Nylon/Hogs Hair 011-0025-00 - 28" Nylon/Hogs Hair



WerkMaster ULTRAguard Sealer

006-0130-04 - 1 QT 006-0152-00 - 1 GAL 006-0130-01 - 2.5 GAL 006-0130-00 - 5 GAL

SDS INFO



WerkMaster Handle and Applicator Pad

006-0140-00 - Pad Holder 006-0141-00 - Handle 006-0138-00 - 18" Scrub Pad 006-0139-00 - 18" Finish Pad



Always test a small area to ensure your products and systems are compatible with the installed polished concrete flooring system. Ensure all sealers and coatings are fully cured before the application of any maintenance products. Always read and follow manufactures directions. Follow all safety guidelines as directed.



Taking it to the Wall!

Allow floor to cure for a minimum of 7 days prior to application of our Maintenance System

Daily Maintenance

Surface Condition: Your floor is dirty and has dulled down slightly.



- 1. Wipe Up spills immediately using a damp cloth.
- 2. Dust mop regularly to maintain dust-free, slip-resistant surface.
- OPTIONAL: Using ULTRAclean HiLite, clean floor with mop/bucket/ wringer and/or auto scrubber and pad. Dilute cleaner to manufactures recommendations.
- 4. Using mop, clean along edges and around stationary objects machine did not reach. Chewing gum will often release during normal cleaning. If not, lift off (DO NOT SCRAPE) immediately after cleaning.
- 5. OPTIONAL: Using pink buffing pad or equivalent, buff floor with WerkMaster machine or burnisher.

Restorative & Periodic Cleaning

Surface Condition: Your floor is dirty and dull and some of the sealer has worn off.



Follow steps 1 – 5 as in daily maintenance

Resealing the floor

Prior to starting, apply ULTRAguard to sample area of each type of surface to be treated, using application procedures proposed for the project.

Confirm that floor surface is receptive to ULTRAguard

- 1. Apply 1 thin coat of ULTRAguard using a pump-up sprayer and microfiber applicator.
- 2. Spread evenly over floor; avoid puddling. Allow to dry 45 minutes.
- 3. If buffing, use a high speed burnisher or WerkMaster machine and pink pad or similar pads.
- 4. Apply a second coat of ULTRAguard repeating Steps 1 and 3

WerkMaster Grinders & Sanders Inc. 6932 Greenwood Street, Burnaby, BC V5A 1X8 tel: 604.629.8700 | toll free: 1.866.373.WERK | fax: 604.444.4231

www.werkmaster.com | email: sales@werkmaster.com

